

Installation Guidance Note: Surestep Digital Print

General Advice

This guidance note should be read in conjunction with our Installation Guidance note for Surestep and Safestep, which details the site requirements and installation procedures for Forbo Surestep products.

The following product specific installation guidance is applicable to Surestep Digitally Printed Safety flooring.

Direction of laying

Sheet lengths should be installed in the same direction.

The finished product will have a selvedge which should be removed so that the seams can be pattern matched and cut.

The pattern repeat will depend on the design.

For further information on bespoke design please contact us: info.bespokedesign.uk@forbo.com

Coved Skirtings

Digitally Printed vinyl can be used in conjunction with standard PVC set in coved skirtings.

If site formed coving is being used for Digitally Printed vinyl, the optimum visual effect will be achieved by laying with a border cove with a contrasting uni colour /all over design.

Seam Welding

All seams should be cold welded with Noviweld 671 cold weld.

Forbo Flooring UK Ltd

Tel: 0800 0282 162

Fax: 01772 646912

Samples: 0800 731 2369

Info.flooring.uk@forbo.com

www.forbo-flooring.co.uk

Additional Reference documents/Information

Additional Reference documents/Information

Installation Guidance note: Surestep and Safestep www.forbo-flooring.co.uk/step

Forbo Floor Coverings Installation Guide. (Tel: 0800 731 2369)

BS8203:2017

The CFA Guide to Contract Flooring (Tel: 01159 411126)