

EASY TO INSTALL

Novilon

Novilon is easy to install on any subfloor, as long as it is level, sound, rigid, clean and permanently dry. The subfloor may first need to be evened out and/or insulated. A specialised fitter can advise you on this. Forbo Flooring has two systems for this purpose:

The Forbo Quickfit system both for wooden and concrete subfloors

A liquid levelling agent for use on stone type subfloors, which is perfectly even when dry.

Would you like to check which subfloor is more suitable in your situation? Please contact your representative and/or local Forbo Flooring organisation by selecting your country from the overview on: [Forbo Flooring Around the Globe](#)

Novilon is available in multiple widths to prevent unnecessary waste when installing.

Novilon can be loose laid up to 40 m². This means that adhesive is not required, but rather only double sided tape along the join of two floor edges. Design floors featuring different colour sections may need to be fully glued. We advise you to have Novilon fitted by a specialised fitter. This will guarantee professional installation.



Novilux

The usual requirements for a subfloor are valid. It must be level, sound, rigid, clean and permanently dry. The subfloor most likely first need to be evened out before installation of your Novilux floor.

Forbo Flooring has two systems for this purpose:

The Forbo Quickfit system both for wooden and concrete subfloors

A liquid levelling agent for use on stone type subfloors, which is perfectly even when dry.

For domestic use Novilux can be loose-laid in an area of up to 20 square metres. All Novilux ranges come in 2 and 4 metre, which makes installation quicker and with minimum seams. Please ensure your Novilux floor is installed in a professional way, following the instructions that come with a product of this nature.

Apart from the actual installation of the floor covering, the installation work involves a wide variety of other products, such as fillers, insulating materials and adhesives. You should always give due consideration to the suitability of these products and the manufacturer's instructions.

Visible defects

Before installing the material, you should check the floorcovering for any defects, colour variations, variations in thickness and optical defects. The manufacturer will not be held liable for defects that were visible before the floorcovering was installed.

Installation of more than one sheet

When installing several sheets in a room, only material from the same production run should be used. You should always mention this when ordering. However, slight differences in colour are also possible within the same production run. In order to avoid any slight differences in colour, the roll numbers of adjacent sheets should be as close as possible to each other. In case of Novilux-Traffic, Novilux-Design en Novilux-Compacta, adjacent sheets should be reverse laid. With Novilux-Natura, Novilux Traffic Wood and Traffic Rock this is not necessary.

Please use the Novilux Technical Manual for more detailed installation information.