



F34



PERMANENT BOND TILE AND PLANK ADHESIVE

Technical specifications

Forbo F34 is a high performance adhesive with excellent initial grab and low VOC, a polymer blend adhesive designed for the installation of commercial and domestic modular luxury vinyl tile/plank. F34 has excellent plasticizer resistance and is to be used on absorbent subfloors. **For indoor use only.**

SUITABLE FOR

- Allura luxury vinyl tile and plank

TYPICAL PROPERTIES

Base	Polymer blend
Solids	Approx. 70%
Shelf life	12 months in sealed container at 20°C
Storage	Store away from high temperatures (<i>direct sunlight and central heating</i>)
Packaging	14 kg/12L drum
Coverage	Up to 5 m ² /L with a V1 trowel

Additional information on physical properties, health hazards, storage, handling, and transport is available in the Safety Data Sheet (SDS), available to download from our website: www.forbo-flooring.com.au/installation.

SURFACE PREPARATION

- All surfaces must be prepared in accordance with the current Australian Standard 1884 'Floor coverings - Resilient sheet and tiles - Installation practices' including moisture and alkaline testing where the relative humidity should not exceed 80% and 10% alkalinity
- All surfaces should be dry, smooth, absorbent and free of any contaminants and old floor coverings that may affect the final bond
- It is recommended that all highly absorbent subfloors be primed with a suitable primer prior to the application of adhesive
- The minimum subfloor temperature prior to commencing preparation or adhesive application is 10°C

DIRECTIONS FOR USE

- Using a V1, 1.6 mm x 1.6 mm x 1.6 mm 'V' notched trowel, spread the adhesive across the subfloor evenly
- Install the PVC tile/plank directly into the wet adhesive without allowing for any tack-up time
- Always check to ensure that complete transfer of adhesive to the floor covering has occurred
- Complete installation of the Forbo product according to instructions, ensuring the installation is rolled in both directions with the recommended roll weight roller, before the adhesive sets
- Do not allow heavy traffic for 24 hours

NOTE: Always carry out your own site test to confirm the suitability of this product with your application.

CLEAN UP

- To remove wet adhesive, use warm soapy water on tools, trowel and floor covering
- Dried adhesive may be softened from tools and the surface of the floor covering using a clean white cloth dampened with mineral turpentine

For further assistance or to obtain a safety data sheet, please contact us on:

1800 224 471, email info.au@forbo.com or visit www.forbo-flooring.com.au/installation.



FLOORING SYSTEMS