

General Advice

All Nuway Connect products are loose laid.

The process of Installation is just the opposite of removal.

Always follow these simple guidelines as an example.

- Always clean the matwell base floor prior to installation.
- Matwell floors must be of a sound construction, dry, smooth and level.
- Do not try to force a mat section into place.
- Always follow the layout drawing and installation literature.

Multi section mats

Install T'-Bars in the inverted format.

Use a screwdriver to lift the mat edge to assist installation.

Install each mat section as per layout drawing supplied.

Each mat section has a lettered label attached and must be placed in the matwell to correspond with the layout drawing.

If required mat sections can be made square, a simple tap with a rubber / nylon hammer should suffice.

Mat sections abut naturally to each other and the T-bar.

There are no fixings.

Removing mat sections

Lift a corner of the mat section using a screwdriver to ease up the mat edge.

Individual mat sections can simply be lifted out of the matwell.

Remember the sequence of removal for correct replacement.

When replacing mat sections, always ensure the same mat section are placed in the same location that it was removed from.

Forbo Flooring recommends that Nuway Entrance systems are installed by a member of the FESSI (Forbo Entrance Systems Specialist Installer) network, details of which can found at the following link:

www.forbo-flooring.co.uk/FESSI