

Nuway Grid: Installation and removal of factory made sections

General Advice

Nuway Grid products are loose laid and there are no clips or joining pieces. The process of installing factory made custom sized mat sections is straightforward and requires no special tools.

- Always clean the mat well base floor prior to installation
- Mat well floors must be of a sound construction, dry, smooth and level.
- Do not try to force a mat section into place
- Always follow the layout drawing and T/bar installation literature if supplied

Multi section mats

Install T'-Bars in the inverted format.
Use a large screwdriver to lift edge of mat to assist installation.

Install each mat section as per layout drawing supplied.
Each mat section has a lettered label attached and must be placed in the mat well (label on the top surface) to correspond with the layout drawing.

Mat sections should be made square, a simple tap with the foot or rubber / nylon hammer should suffice.

The sections abut naturally to each other and the T-bar.
There are no fixings.

Removing mat sections

The mat sections can be lifted using a screwdriver to ease up the edge each piece.
Remember the sequence of removal for correct replacement.
If reversing and/or alternating the sections, ensure the same size sections are placed in the same location.

Forbo Flooring recommends that Nuway Entrance systems are installed by a member of the Forbo Entrance Systems Specialist Installer (FESSI) network.

Details on the following link: www.forbo-flooring.co.uk/FESSI

Contact us:

Forbo Flooring UK Limited
PO Box 1
Kirkcaldy
KY1 2SB

www.forbo-flooring.co.uk
email: info.flooring.uk@forbo.com
Telephone: 0800 0282 162
Fax: 01772 646 912