

Floor Care Guidelines for Allura Luxury Vinyl Tile

The Forbo Allura product range includes: Allura Wood Authentic and Allura Flex.

Forbo Allura Wood Authentic luxury vinyl tiles are comprised of a vinyl wear layer with a high performance PUR topcoat which provides color clarity. A calendared wear layer provides clear image, superior strength and durability. The thick glass interlayer ensures dimensional stability, flexibility, tension releases and strength with a thick solid backing for comfort, balance and support of the wear layer. Allura Flex is comprised the same, but also has a mechanical foam back layer that contributes to its acoustical properties.

NOTE:

In order to allow the adhesive to dry and cure properly, wait a minimum of five days following the installation before conducting initial cleaning or other wet cleaning procedures. For installations over non-porous substrates, additional time may be necessary because the adhesive may take longer to dry and cure.

INITIAL CLEANING

For new installations exposed to normal construction soil and traffic.

1. Remove all surface soil, debris, sand and grit by sweeping, vacuuming or dust mopping.
2. Mix a neutral pH cleaning solution according to the label directions.
IMPORTANT: The pH of the cleaner in solution must be between 6 – 8 pH. Please refer to the list at the end of this section for recommended products.
3. Apply the solution to the floor. Do NOT flood the floor. The solution can be applied with either a mop and bucket or an automatic scrubber.
4. Scrub the floor with a rotary scrubber or automatic scrubber using a 3M™ Red Buffer Pad #5100 or equivalent.
NOTE: For heavier soil loads, a 3M™ TopLine Autoscrubber Pad #5000 or equivalent may be used.
5. If not using an automatic scrubber, pick up the scrubbing solution with a wet vacuum (preferred) or a squeegee and a mop.
6. Rinse the entire floor surface with a clean mop using clean, cool water. Pick up rinse water with wet vacuum or automatic scrubber.
7. Allow the floor to dry thoroughly before allowing traffic.

ROUTINE CLEANING

Cleaning performed a minimum of once a day, depending on the application, type of traffic and hours of operation.

1. Stains or spills should be wiped or mopped up immediately with a damp mop using a neutral pH cleaning solution. Rinse the affected area with clean, cool water. Be sure to allow the floor to dry thoroughly before allowing traffic.
IMPORTANT: The pH of the cleaner in solution must be between 6 – 8 pH. Please refer to the list at the end of this section for recommended products.
2. Remove all surface soil, debris, sand and grit by sweeping, vacuuming or dust mopping.
3. Mix a neutral pH cleaning solution according to the label directions.
IMPORTANT: The pH of the cleaner in solution must be between 6 – 8 pH. Please refer to the list at the end of this section for recommended products.
4. Apply the solution to the floor. Do NOT flood the floor. The solution can be applied with either a mop and bucket or an automatic scrubber with a 3M™ Red Buffer Pad #5100 or equivalent.
NOTE: For heavier soil loads, a 3M™ TopLine Autoscrubber Pad #5000 or equivalent may be used.
5. Rinse the entire floor surface with a clean mop using clean, cool water. Pick up rinse water with wet vacuum or automatic scrubber.
6. Allow the floor to dry thoroughly before allowing traffic.

Floor Care Guidelines for Allura Luxury Vinyl Tile

INTERIM CLEANING

As needed, depending on the application, type of traffic and hours of operation.

1. Remove all surface soil, debris, sand and grit by sweeping, vacuuming or dust mopping.
2. Mix a neutral pH cleaning solution according to the label directions.
IMPORTANT: The pH of the cleaner in solution must be between 6 – 8 pH. Please refer to the list at the end of this section for recommended products.
3. Apply the solution to the floor. Do NOT flood the floor. The solution should be applied with either a mop and bucket or an automatic scrubber.
4. Scrub the floor with a rotary scrubber or automatic scrubber using a 3M™ Red Buffer Pad #5100 or equivalent for light soiling, a 3M™ TopLine Autoscrubber Pad #5000 or equivalent for medium soiling or a 3M™ Blue Cleaner Pad #5300 or equivalent for heavy soiling.
5. If not using an automatic scrubber, pick up the scrubbing solution with a wet vacuum (preferred) or a squeegee and a mop.
6. Rinse the entire floor surface with a clean mop using clean, cool water. Pick up rinse water with wet vacuum or automatic scrubber.
7. Allow the floor to dry thoroughly before allowing traffic.
8. If desired, one of the following procedures can be performed:
 - a. Spray buff the floor using a 175 RPM swing machine and a 3M™ Red Buffer Pad #5100 or equivalent, followed by dust mopping.
 - b. Apply a mop-on restorer and burnish using a 3M™ Eraser Pad #3600 or equivalent, followed by dust mopping.
 - c. Burnish / Dry Buff the floor using a 3M™ Eraser Pad #3600 or equivalent, followed by dust mopping.
9. If the floor requires restoration cleaning procedures, contact Forbo Technical Services.

NOTE:

Weather, traffic and geographical location will influence the required frequency of this procedure. For example, in areas where there are large amounts of snow and chemicals used in the winter months it will likely be necessary to perform this procedure more frequently. In dry climates, or where there is less dirt traffic, it may not be necessary to perform this procedure as frequently.

RECOMMENDED FLOOR CARE PRODUCTS

Neutral pH Cleaners:

Forbo Neutral pH Cleaner
ProLink Level 7
Spartan Damp Mop
3M™ Neutral Cleaner 3H
Diversey Stride

Spray Buffs:

Forbo Spray Buff
ProLink Enhance
Spartan Spray Buff
3M™ Top Line Pre-Burnish Conditioner
Diversey Snapback

Mop on Restorers:

Forbo Mop on Restorer
ProLink Optimum Response
Spartan SunSwept
3M™ Top Line Pre-Burnish Conditioner
Diversey Snapback UHS

For additional information on a product or for your local supplier, contact:

Forbo Flooring Systems
+800 842 7839
www.forboflooringNA.com

Spartan
+800 537 8990
www.spartanchemical.com

Diversey
+800 558 2332
www.diversey.com

ProLink
+800 745 4657
www.prolinkhq.com

3M™
+800 852 9722
www.3m.com/building

Forbo's Floor Care Guide contains additional information about floor care and is available for download at www.forboflooringna.com. For a hard copy, or for additional information, contact Forbo Technical Services at +800 842 7839.