

General Advice

The installation of Allura should be carried out in accordance with AS 1884-1985 "Resilient Sheet and Tiles - Laying and Maintenance Practices". As with all resilient floor coverings, bases should be clean, smooth, sound and permanently dry.

For standard installations Forbo Flx 540 adhesive is recommended or Forbo V885.

It is important to note that areas of installation liable to be subjected to abnormal temperature variation in use, for example, premises with glazed window fronts, glazed patio doors, conservatories etc. must be adhered with Eurocol 'Euromix PU' which is a two part rigid set polyurethane adhesive.

Acclimatisation

Prior to installation, boxes of tiles should be removed from the delivery pallet and stored not more than five boxes high in the laying area for at least 24 hours. The conditioning time should be extended to 48 hours if materials have been stored or transported at temperatures less than 10°C immediately prior to delivery.

Installation options

Most Allura designs are non-directional; however, the following installation advice is given.

- Stone tiles may be laid either in bond (broadloom) or brick pattern.
- Textile designs should be installed chequerboard.

Tiles and planks do not require shuffling prior to installation, but dry laying will identify best use of design. Please note that abstract stripe designs do not have a pattern match.

Like the natural material, some designs will vary in tone and colour. This is intentional and gives the floor a more authentic appearance.

Points to note

As with all Forbo floor coverings, Allura can be used in conjunction with under-floor heating systems.

A separate guidance note "[Installation of Forbo PVC and Linoleum Floor Coverings on Underfloor Heating Systems](#)" provides more information on the conditions for installation in such circumstances.

- Only spread sufficient adhesive that can be covered within the specified open time.
- Allura tiles should be rolled with a 68 kg roller as soon as possible after laying and within the open time of the adhesive – the open time of the adhesive will depend on site conditions and porosity of the base.
- Always clean away excess adhesive with a damp cloth before it is allowed to dry.
- Allura should be protected from heavy traffic for 24 hours and must not be wet cleaned for 48 hours after installation.