

Caring for Marmoleum® Wall Products

The Forbo Marmoleum® Wall product range includes: Marmoleum® & Walton sheet and Marmoleum® Wall Panels.

The Forbo Marmoleum® features Topshield2™, a waterborne UV cured double layer factory coating. This finish has been designed to meet the demands of everyday use and is even more resistant to dirt absorption, less prone to wear and has improved resistance to scratches and stains, and thus demonstrating lasting performance over time.

There are a few key points to remember when caring for these products:

- Stains should be removed as quickly as possible to eliminate permanent damage.
- Excess soiling materials such as chewing gum, nail polish, lipstick, asphalt, crayon, ink, marker, paint, lacquer, enamel, tar or foodstuffs should be removed or carefully scraped off the flat side of a plastic scraper prior to any other cleaning attempts below.
- For tough soiling materials, Forbo Adhesive Remover can be used.

IMPORTANT! Before starting any cleaning procedures on any Forbo products, contact Forbo's Product Support & Education Services for additional information, recommendations or to schedule a site visit. The best results may not be achieved if the chemical and equipment types recommended below are not used.

NOTE: Forbo Flooring Systems does not warrant or guarantee the performance of other manufacturers' products mentioned in these guidelines. For specific information regarding Forbo's warranty, visit www.forboflooringNA.com or contact Forbo's Product Support & Education Services.

USING FORBO ADHESIVE REMOVER

1. Always test in a hidden area first.
2. Apply Forbo Adhesive Remover using a soft bristled brush, cloth or sponge.
3. Allow the product to penetrate for 3-5 minutes (longer in cold temperatures).
4. Agitate the area with the brush, cloth or sponge. Some soiling loads may require extra contact time or repeat applications.
5. Rinse thoroughly with water.
6. Allow the spot to dry completely.

CARE RECOMMENDATIONS

1. Remove all surface soil, debris, sand and grit by dusting with 3M™ Easy Trap.
2. Mix a neutral pH cleaning solution according to the label directions. The pH of the cleaner in solution must be between 6.0 – 8.0 pH. Refer to the list at the end of this section for recommended products.
3. Apply the solution with a microfiber cloth or sponge.
4. Wipe the area to loosen and remove any soil.

NOTE: For heavy soil loads or difficult to remove soil deposits, the use of a soft bristled brush is recommended.
5. Rinse the area thoroughly with clean, cool water. Change the water often to ensure it remains clean and clear.
6. Dry the area thoroughly with an absorbent cloth so it can be examined to ensure proper cleaning.

CAUTION: Forbo Marmoleum Wall products can be damaged by abrasive or caustic chemicals or procedures. If the above recommendations are followed, no additional chemicals or procedures will be required. If such chemicals or procedures are or have been used, contact Forbo's Product Support & Education Services for additional information.

RECOMMENDED CARE PRODUCTS

The following list of recommended floor care chemicals have been tested for compatibility with Forbo products. This list is provided to offer the best opportunity to care for your flooring and meet the needs of your facility. **If you prefer to use a manufacturer's floor care chemicals that are not listed, be sure to use a corresponding cross-referenced product.** For additional information on a product or for your local supplier, refer to the Contacts section of the Forbo Commercial Floor Care Guide.

Neutral pH Cleaners

Forbo Neutral pH Cleaner
 3M™ Neutral Cleaner 3H
 Pro-Link Level 7
 Spartan Damp Mop
 Diversey Stride
 Ecolab® QC 34 High Performance Neutral Floor Cleaner

Spot Cleaner

Forbo Adhesive Remover

Forbo's Commercial Floor Care Guide contains additional information and is available for download at www.forboflooringNA.com. For a hard copy, or for additional information, contact Forbo's Product Support & Education Services at 1-800-842-7839.