

FORBO MATTE FLOOR FINISH TECHNICAL DATA

1. PRODUCT NAME & MANUFACTURER

1.1 Product:

Forbo Matte Floor Finish

1.2 Manufacturer:

Forbo Flooring Systems US
8 Maplewood Drive
Hazleton, PA 18202
1-800-842-7839

Forbo Flooring Systems Canada
3983 Nashua Drive, Unit 1
Mississauga, ON L4V 1P3
1-800-268-8108 (English)
1-800-567-9268 (French)

www.forboflooringNA.com

1.3 Product Description:

Forbo Matte Floor Finish is a floor finish specially formulated with elastic properties that will prevent cracking. There are no heavy metals or zinc in the finish that can be harmful to wastewater treatment systems. It is designed to protect the floor and stand up to heavy wear and traffic.

1.4 Recommended for Use With:

Marmoleum
Eternal
Sphera (non-ESD applications)
Allura

1.5 Physical Characteristics:

Odor ----- Characteristic
Color ----- White emulsion
pH ----- 8.0 – 9.0
VOC Content ----- None
Unit Size ----- 1 gallon (3.785 L)
Dilution ----- Do NOT Dilute
Spread Rate ----- 1,800 – 2,000 square feet per gallon
Shelf Life ----- 2 years in unopened container
Storage ----- Keep from Freezing
Disposal ----- Follow all local regulations

2. APPLICATION RECOMMENDATIONS

Remove all surface debris by dust mopping, sweeping or vacuuming. Mix a cleaning solution by diluting a neutral pH cleaner in strict accordance with the manufacturer's recommendations. The pH of the cleaning solution must be between 6.0 – 8.0 pH. Apply the cleaning solution to the floor and allow 5 – 10 minutes of dwell time. Additional dwell time may be necessary for heavily soiled floors. Scrub the floor with either a 175 RPM floor machine or an automatic scrubber using a 3M Cleaning Pad #5100 or equivalent. For heavier soil loads or to remove adhesive residue, use a 3M Topline Pad #5000 or equivalent, but this pad is NOT to be used regularly in place of the 3M Cleaning Pad #5100. Pick up the cleaning solution with a wet/dry vacuum or an automatic scrubber. If using a cleaner that requires rinsing, rinse the entire surface with a clean mop using clean, cool water. Pick up the rinse water with a wet/dry vacuum or an automatic scrubber. Allow the floor to dry completely. Apply 1 – 2 coats of Forbo Matte Finish using a clean microfiber applicator or a clean finish mop. Allow a minimum of 45 minutes drying time between coats or before allowing traffic.

3. ADDITIONAL INFORMATION

See Forbo's Floor Care Guidelines specifically created for each Forbo product for more detailed recommendations when using Forbo Matte Floor Finish.

For additional information, contact Forbo's Product Support & Education Services at 1-800-842-7839 or visit www.forboflooringNA.com.