

# eurocol

# 520

the strong connection

23-3-2026

## LINOLEUM DOCTOR

Renovation adhesive to repair hollow areas under linoleum, pressure sensitive and hardens fast after rubbing down the injected adhesive under the floor covering.



### PRODUCT TYPING

|             |                   |
|-------------|-------------------|
| Base        | Latex-dispersion. |
| Consistency | Thin liquid.      |

- Pressure sensitive renovation adhesive to repair hollow areas under linoleum.
- Hardens fast after rubbing down the injected adhesive under the floor covering.
- Suitable over underfloor heating systems.
- Castor wheel resistant according to DIN EN 12529.
- For indoor use only.

### PROPERTIES

|                  |                              |
|------------------|------------------------------|
| Consumption      | Is based on the damage area. |
| Flammability     | Non-flammable.               |
| Frost resistance | No.                          |
| Special quality  | Tool kit included.           |
| Specific weight  | 0.9 kg/l                     |

### APPLICATION

To repair hollow areas under linoleum.

### PROCESSING

|              |                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Storage      | Store cool and free from frost.                                                                                                                                                                                                                                                                                                                                                                                          |
| Tools        | Tool kit included.                                                                                                                                                                                                                                                                                                                                                                                                       |
| Curing       | Approx 24 hours.*                                                                                                                                                                                                                                                                                                                                                                                                        |
| Open time    | 20 minutes.*                                                                                                                                                                                                                                                                                                                                                                                                             |
| Waiting time | None.                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Shelf Life   | 12 Months, in unopened packaging. After use close the open packaging well.                                                                                                                                                                                                                                                                                                                                               |
| Cleaner      | Water.                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Remarks      | Please pay attention to the technical datasheet and technical datasheet issued by the floor covering.<br>When using brushed, only use of latex brushes is recommended. Brushing with conventional brushed leads to coagulations of the adhesive which becomes then useless.<br>After the repair, it is advisable to clean the floor. Eurocol recommends 898 Euroclean Longlife. Wear protective gloves / eye protection. |

\* The stated values are laboratory values which, given the large variation in climatological conditions, subfloor compositions and layer

520 LINO DOCTOR

thicknesses, are only guideline values.

#### Substrate:

- One of the materials to be bonded must be water absorbent.
- Only hollow areas that have not been created by the effects of moisture from the substrate can be renovated.

#### Instruction manual:

- Before use, temper the product according to the processing conditions.
- Shake before use!
- Drill hollow areas with a 4 mm drill bit. Draw the repair adhesive into the syringe supplied and inject it under the hollow area.
- Immediately spread the adhesive from the centre outwards with a hammer and rub from the outside inwards.
- If any adhesive leaks out, immediately absorb it with a damp cloth and clean the area with clear water.
- The adhesive immediately builds up strength so that reworking is generally not necessary.  
The drill hole can be sealed "invisibly" with a fusible wire.

#### Processing conditions:

at least 15 °C floor temperature,  
at least 18°C material and room temperature,  
35-75% relative humidity, recommended <65%.

## ENVIRONMENT AND HEALTH

|                            |                                                                                                                                                                                                                                                                                             |
|----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Safety and environment     | Safety data sheets of Forbo Eurocol products according to EEG-guideline 91/155. Keep out of reach of children. Do not eat, drink or smoke while processing the product. Only give completely empty containers for recycling. Bound material residues can be disposed of as household waste. |
| MSDS                       | Available on request.                                                                                                                                                                                                                                                                       |
| Substances causing allergy | Contains natural latex. May produce an allergic reaction.                                                                                                                                                                                                                                   |

## ITEM DATA

| Article | Productname           | Packaging                                   | Shipping unit |
|---------|-----------------------|---------------------------------------------|---------------|
| 520     | Linoleum Doctor - Set | plastic bottle à 0,5 kg, 2 syringes per box | 264/pallet    |

Any application method/ conditions other than specified in this Technical data sheet require explicit manufacturer's approval. In case of deviance in application method/ conditions liability by manufacturer cannot be guaranteed. This technical data sheet contains advice on handling and application of the product, based on experience and tests run by the manufacturer in laboratory and practical work. The information supplied by the manufacturer are non-binding and cannot be used as a basis for establishing the manufacturers liability for any damages caused. The values stated in this technical data sheet were measured under standard laboratory conditions. As application conditions outside the laboratory vary strongly this technical data sheet must be considered a guide only. Therefore the manufacturer does not take liability for damages caused by the customer's utilization of the technical data sheet content. As use, processing- and storage conditions on site are beyond manufacturers influence, a warranty for the processing result cannot be given. This also includes the infringement of any rights for the protection of third parties. Sufficient testing areas are to be provided before final application. Relevant national norms and regulations of the industry are to be observed. Outside Germany valid, relevant national norms and regulations, have to be taken into account and to be followed by the customer. It is the responsibility of the customer to check product suitability for the intended procedure and purposes prior to use.

This Technical Information supersedes all previously issued application data sheets and product information are no longer valid!

BG173150, Version V03, Stand 2016-12-06, ersetzt Ausgabe vom 2009-04-29

## 520 LINO DOCTOR