# eurocol **051**



the strong connection

# **EUROPRIMER QUARTZ**

Primer for impervious surfaces, very low emission, emicode EC 1PLUS, ready for use, user friendly, for wall and floor and suitable for underfloor heating systems.

# **PRODUCT TYPING**

Base	Acrylic dispersion.		
Color	Light pink.		
<ul> <li>Very low emission</li> <li>Emicode EC 1PLU</li> <li>Ready for use</li> <li>Resistant against</li> <li>User friendly</li> <li>Suitable indoors</li> <li>For wall and floor</li> <li>Suitable for unde</li> <li>Improves the adh</li> </ul>	JS alkaline moisture , rrfloor heating systems		
PROPERTIES			

Aging	051 Europrimer Quartz does not deteriorate with age.		
Alkali resistance	051 Europrimer Quartz is resistant against alkaline moisture.		
Classification	Emicode EC 1PLUS tested conform EN 13999-2/4. Suitable for BREEAM-projects.		
Consumption	0.1 - 0.3 kg/m <sup>2</sup> , depends on the type of roller or brush.		
Frost resistance	After drying moisture resistant and therefore suitable for use in "wet spaces". 051 Europrimer Quartz cannot be applied outside or underwater (pool basins).		
Humidity resistance	After drying moisture resistant and therefore suitable for use in "wet spaces". 051 Europrimer Quartz cannot be applied outside or underwater (pool basins).		

# APPLICATION

Primer for closed substrates, e.g. existing wall and tile work and concrete enamel, onto which new tiles are glued or which are finished with a cement or plaster-bound wall-levelling.

# PROCESSING

Storage	Store free from frost. Protect against high temperatures.		
Tools	Lambswool roller or brush.		
Drying	2 - 4 Hours, depending on subfloor, application and temperature.		
Moisture resistance	After drying moisture resistant and therefore suitable for use in "wet spaces". 051 Europrimer Quartz cannot be applied outside or underwater (pool basins).		

#### 051 EUROPRIMER QUARTZ

Forbo Eurocol Nederland B.V. | Industrieweg 1-2 | Postbus 130 | 1520 AC Wormerveer | Tel: +31 (0)75 627 16 00 | info.eurocol@forbo.com Forbo Eurocol Deutschland GmbH | August-Röbling-Straße 2 | DE - 99091 Erfurt | PF 80 02 53 | Telefon: +49 361 730 41 0 | info.eurocol.de@forbo.com



\* The stated values are laboratory values which, given the large variation in climatological conditions, subfloor compositions and layer thicknesses, are only guideline values.

#### Substrate:

- The subfloor should be clean, free from grease and dirt, dry and have a good tensile and compression strength, according to the requirements of DIN 18 353 and DIN 18 365.
- Degrease the subfloor well with 014 Euroclean.
- In advance always seek our technical data sheets. In doubt about the application ask for technical advice.

#### Instruction manual:

- Before use manually stir the 051 Europrimer Quartz.
- After stirring apply the primer thin and equally with a lambswool roller or brush.
- Drying time 2 to 4 hours, depending on the subfloor, application, moisture percentage and temperature.
- Thereafter finish the subfloor with a cement or gypsum based levelling compound or tile adhesive.

Contains methylchloroisothiazolinone and methylisothiazolinone (3:1) and benzisothiazolinone. May produce an allergic reaction.

## **QUALITY AND GUARANTEE**



# **ENVIRONMENT AND HEALTH**

Safety and environmentSafety data sheets of Forbo Eurocol products according to EEG-guideline 91/155.MSDSFor extensive information about safety and environment we refer to our website www.eurocol.nl.

# **ITEM DATA**

Definition	Packaging	EAN-code	
Europrimer Quartz	7 kg bucket	8 710345 005128	
Europrimer Quartz	14 kg bucket	8 710345 005104	
Europrimer Quartz	Box of 12x1.5 kg Bucket	8 710345 005142	
Europrimer Quartz	1.5 kg Bucket	8 710345 051552	12 pieces
	Europrimer Quartz Europrimer Quartz	Europrimer Quartz 7 kg bucket Europrimer Quartz 14 kg bucket	Europrimer Quartz7 kg bucket8 710345 005128Europrimer Quartz14 kg bucket8 710345 005104Europrimer QuartzBox of 12x1.5 kg Bucket8 710345 005142

#### **051 EUROPRIMER QUARTZ**

