

eurocol 150

the strong connection



PARQUET DOCTOR

For repair of hollow spots under parquet

PRODUCT TYPING

Base	1-C PUR
Color	Brown.
Consistency	Liquid.

- Low-viscosity, moisture-curing PUR adhesive.
- For the small-surface repair of hollow areas under parquet flooring.
- Cavity filling through slight foaming.

PROPERTIES

Consumption	depending on the cavity under the parquet.
Flammability	Non-flammable.
Frost resistance	Yes.
Special quality	For the repair of hollow areas under parquet flooring.

APPLICATION

for the small area repair of hollow areas under glued parquet.

PROCESSING

Storage	Store cool and dry in unopened packaging.
Tools	Directly from the bottle.
Curing	Approx 12 hours.*
Shelf Life	Approx 12 months, in unopened packaging. After use close the open packaging well.
Cleaner	815 Euroclean HandClean, 358 ToolCleaner.
Application temperature	TODD
Remarks	Technical information and safety data sheets of any laying materials and parquet used must be observed! Not a consumer product according to 1999/EG/44.

* The stated values are laboratory values which, given the large variation in climatological conditions, subfloor compositions and layer thicknesses, are only guideline values.

Instruction manual:

- Before use, temper the product according to the processing conditions.

150 PARQUET DOCTOR

- Isolate the hollow area, secure the drilling point with adhesive tape to prevent it from breaking out and becoming dirty.
- Drill the hole and inject adhesive. Use disposable syringes if necessary.
- Remove excess adhesive. Remove adhesive tape and weigh down for several hours until the adhesive has set.
- Close the drilled hole with a wooden dowel in the same colour.

ENVIRONMENT AND HEALTH

GISCODE	RU1
Hazard Class	Contains hazardous ingredients. Please observe the notes in the Safety data sheet!
Safety and environment	Safety data sheets of Forbo Eurocol products according to EEG-guideline 91/155. Keep out of reach of children. Do not eat, drink or smoke while processing the product. Only give completely empty containers for recycling. Bound material residues can be disposed of as household waste. From 24.8.2023, training is mandatory for handling preparations containing isocyanates. https://isopa-aisbl.idloom.events/049-de
MSDS	For detailed information about the safety measures please refer to the safety information sheet on our website www.forbo-eurocol.de .
Substances causing allergy	Contains isocyanates. May produce an allergic reaction.

ITEM DATA

artikel	productname	packaging	shipping unit
150	Parquet Doctor	plastic bottle à 0,75 kg 6 bottles per box	720/pallet

Any application method/ conditions other than specified in this Technical data sheet require explicit manufacturer's approval. In case of deviance in application method/ conditions liability by manufacturer cannot be guaranteed. This technical data sheet contains advice on handling and application of the product, based on experience and tests run by the manufacturer in laboratory and practical work. The information supplied by the manufacturer are non-binding and cannot be used as a basis for establishing the manufacturer's liability for any damages caused. The values stated in this technical data sheet were measured under standard laboratory conditions. As application conditions outside the laboratory vary strongly this technical data sheet must be considered a guide only. Therefore the manufacturer does not take liability for damages caused by the customer's utilization of the technical data sheet content. As use, processing- and storage conditions on site are beyond manufacturer's influence, a warranty for the processing result cannot be given. This also includes the infringement of any rights for the protection of third parties. Sufficient testing areas are to be provided before final application. Relevant national norms and regulations of the industry are to be observed. Outside Germany valid, relevant national norms and regulations, have to be taken into account and to be followed by the customer. It is the responsibility of the customer to check product suitability for the intended procedure and purposes prior to use.

This Technical Information supersedes all previously issued application data sheets and product information are no longer valid!

BG146580, Version 02, Stand 2018-09-04, ersetzt Ausgabe vom 2008-03-11.

150 PARQUET DOCTOR