

**REPORT** issued by an Accredited Testing Laboratory

Contact person RISE Ulrika Johansson Chemistry and Materials +46 10 516 53 22 ulrika.johansson@ri.se

Date 2020-06-12

Page 1 (5) Forbo Flooring AB Box 90173 120 22 STOCKHOLM

Reference

2F012003

# **Emission measurements according to M1**

(3 appendices)

### Assignment

Emission measurement according to "M1 Emission Classification of Building Materials: Protocol for Chemical and Sensory Testing of Building Materials", ver 15.11.2017, after 28 days of conditioning regarding volatile organic compounds, carcinogenic compounds (EU Regulation No 1272/2008 Annex VI, cat 1A and 1B), formaldehyde, ammonia and sensory acceptability.

### Product/test specimen

Table 1.	
Product type:	Flooring, LVT tiles
Product name:	Allura Ease/Puzzle 63496EA7
Manufacturer:	Forbo Flooring AB
Manufacturing date:	2020-03-23
Sampling date:	2020-04-03
Batch No:	59766
Size of sample, packaging:	10 tiles, 120 x 19 cm in a retail package packed in plastic foil
Arrived at RISE:	2020-04-07
Test specimen preparation:	Wall scenario is used for the testing. Chemical testing: Two pieces of 31 x 19 cm were cut out. They were placed back-to-back and the edges and part of the front sides were sealed with aluminium tape leaving a total exposed surface area of $0.11 \text{ m}^2$ . Sensory testing: Four pieces of 91 x 19 cm were cut out. They were placed back-to-back, two and two, and the edges and parts of the front sides were sealed with aluminium tape leaving a total exposed surface area of $0.65 \text{ m}^2$ .
Deviation from protocol:	No
Test period started, date:	2020-04-09
Conditions during ageing:	23 ± 2 °C, 50 ± 5 % RH
Emission samplings, date:	2020-05-07

### **RISE Research Institutes of Sweden AB**

Postal address Box 857 SE-501 15 BORÅS Sweden Office location Brinellgatan 4 SE-504 62 BORÅS

Phone / Fax / E-mail +46 10 516 50 00 +46 33 13 55 02 info@ri.se This report may not be reproduced other than in full, except with the prior written approval of the issuing laboratory.



### **Methods**

The specimens were conditioned outside the testing chambers in a room with controlled climate conditions of  $23 \pm 2$  °C and  $50 \pm 5$  % RH. The specimens were placed in the chambers three days before the measurements of the chemical emission and the sensory evaluation.

#### Table 2.

Chamber conditions of the test of chemical emissions

Test chamber volume:	0.27 m <sup>3</sup> , stainless steel
Temperature:	$23 \pm 1$ °C
Relative Humidity:	$50 \pm 3$ % RH
Air exchange rate:	$0.5 \text{ h}^{-1}$
Air velocity at specimen surface:	0.1 – 0.3 m/s
Area of sample:	$0.11 \text{ m}^2$
Area specific air flow rate:	$1.23 \text{ m}^3/\text{m}^2\text{h}$

Date

### Table 3.

Chamber conditions of the test of sensory acceptability

Test chamber volume:	1.0 m <sup>3</sup> , stainless steel
Temperature:	$23 \pm 1$ °C
Relative Humidity:	$50 \pm 3 \% RH$
Supply air flow rate:	$0.9  l/s = 3.2  m^3/h$
Area of sample:	$0.65 \text{ m}^2$

### Table 4.

Emission sampling and analytical methods

Test	Sampling method	Adsorbent	Sampling volume (litre)	Analysis method / Quantification	Detection limit
VOC	ISO 16000-9:2006 <sup>1</sup>	Tenax TA	4.3 - 6.1	SP 0601 <sup>2</sup> / FID quantification	$1 \mu g/m^3$
Formaldehyde	ISO 16000-9:2006 <sup>1</sup>	DNPH	32	SP 2303 <sup>3</sup> /HPLC-UV	0.03 µg/sampler
Ammonia	ISO 16000-9:2006 <sup>1</sup>	Treated silica gel	261 - 310	Liquid chromatograph with conductivity detector <sup>4</sup>	1.0 µg/sampler
Sensory evaluation	ISO 16000-28:2012 <sup>5</sup>			Acceptability, Untrained panel of min 15 persons	

<sup>1)</sup> In accordance with ISO 16000-9:2006 and M1 protocol.

<sup>2)</sup> In accordance with ISO 16000-6:2011 and M1 protocol.

<sup>3)</sup> In accordance with ISO 16000-3:2001.

<sup>4)</sup>Not accredited method.

<sup>5)</sup> In accordance with M1 protocol, not accredited method.

Tenax TA was used as adsorption medium for VOC The tubes were thermally desorbed and analysed in accordance to SP method 0601, similar to ISO 16000-6:2011 (Determination of volatile organic compounds in indoor and test chamber air by active sampling on Tenax TA sorbent, thermal desorption and gas chromatography using MS/FID). This means an analysis in a gas chromatograph and detection with a flame ionisation detector (FID) and mass selective detector (MS). The FID signals are used for compound quantification. The TVOC is quantified as toluene equivalents. The mass selective detector is used for identification of compounds. The capillary column used is coated with 5% phenyl/95 % methylpolysiloxane. Tenax TA was

### **RISE Research Institutes of Sweden AB**



also used as adsorption medium for testing of volatile carcinogenic compounds, according to EU Regulation No 1272/2008 Annex VI, cat 1A and 1B), (exclusive formaldehyde), 0.001 mg/m<sup>3</sup> and above.

The sampling of formaldehyde was carried out with DNPH samplers. The samplers were analysed according to SP method 2302, similar to ISO 16000-3:2011(Indoor air--Part 3: Determination of formaldehyde and other carbonyl compounds – Active sampling method), which means analysis on a liquid chromatograph with absorbance detector.

The sampling of ammonia was carried out with silicagel treated adsorbent tubes and analysis on a liquid chromatograph with conductivity detector.

Minimum two subsequent samples were taken for the determination of VOC, formaldehyde and ammonia respectively.

### Results

The results relate only to the items tested.

Decision rule: When comparing the measured results and requirement level, the average value of the measured results has been compared with the requirement level. No account is taken to the measurement uncertainty.

The results of the chemical testing are expressed as area specific emission rates and as concentrations in a model room. The model room has a base area of 3 m x 4 m and a height of 2.5 m, with an air exchange rate of  $0.5 \text{ h}^{-1}$ . The wall area is  $31.4 \text{ m}^2$ , floor area is  $12 \text{ m}^2$ , small area, like a door, is  $1.6 \text{ m}^2$  and very small area, like sealant, is  $0.2 \text{ m}^2$ . Floor area is used for the calculation of the concentrations.

Calculation of the concentration from the emission rate:

	Conc = concentration of a VOC in the model room, in $\mu g/m^3$
	$SER_a$ = area specific emission rate, in $\mu g/m^2h$
$SER_A \times A$	A = area of sample, in $m^2$
$Conc = \frac{1}{n \times V}$	n = air exchange rate, in changes per hour
	V = volume of the model room, in m <sup>3</sup>

Table 5.

Results of the chemical testing of the sample Allura Ease/Puzzle 63496EA7, after 28 days

Compound	<b>Concentration in</b> <b>model room</b> mg/m <sup>3</sup>	<b>Emission rate</b> mg/m <sup>2</sup> h	<b>Criteria M1</b> mg/m <sup>2</sup> h
TVOC <sup>6</sup>	0.007	< 0.010	< 0.2
Carcinogens	< 0.001	< 0.001	< 0.001
Single VOC ( $\mu g/m^3$ )	≤ EU-LCI		$\leq$ EU-LCI
Formaldehyde	0.002	0.003	< 0.05
Ammonia <sup>7</sup>	< 0.003	< 0.004	< 0.03

<sup>6)</sup> The TVOC is the sum of the individual concentration  $\geq 5 \ \mu g/m^3$  in model room.

<sup>7)</sup> Not accredited method.

Date



#### Table 6.

Results of the sensory acceptability evaluation of the sample Allura Ease/Puzzle 63496EA7, after 28 days

Evaluator	Sensory evaluation	Criteria M1
1	1.00	
2	0.95	
3	0.92	
4	0.98	
5	0.96	
6	0.60	
7	0.97	
8	0.77	
9	1.00	
10	0.88	
11	0.95	
12	0.96	
13	0.95	
14	0.96	
15	0.96	
Arithmetic mean of acceptability <sup>8</sup>	0.92	$\ge + 0.0$
Standard deviation	0.11	
90 % confidence interval of arithmetic mean	0.04	$\leq 0.2$

<sup>8)</sup> Not accredited method.

The empty sensory test chamber acceptability was determined 2020-05-04. The mean acceptability vote of the empty chamber was > 0.8.

### Interpretation of the results

The tested product Allura Ease/Puzzle 63496EA7 complies with all the requirements of M1 for the tested parameters.

### **Detailed results**

Table 7. Detailed results (emission rates) of the chemical testing after 28 days

Sample	$\frac{\text{TVOC}}{(\text{mg/m}^2\text{h})}$ as toluene equivalents between C <sub>6</sub> -C <sub>16</sub>	Formaldehyde (mg/m <sup>2</sup> h)	Ammonia (mg/m <sup>2</sup> h)	$\begin{array}{c} \textbf{Carcinogens} \\ (mg/m^2h) \\ \text{between } C_6\text{-}C_{16} \end{array}$
1	< 0.010	0.002	< 0.004	< 0.001
2	< 0.010	0.003	< 0.005	< 0.001

#### Table 8.

KI SE

Single VOCs above  $5 \mu g/m^3$  in the model room (floor area scenario)

Single VOCs	CAS number	Retention time (min)	<b>ID</b> <sup>9</sup>	Emission rate $(\mu g/m^2h)$	$\begin{array}{c} \textbf{Concentration} \\ (\mu g/m^3) \end{array}$
Single VOCs C <sub>6</sub> -C <sub>16</sub> :		6.9 - 39			
1-Heptanol, 2-propyl-	10042-59-8	27.6	В	9	7
TVOC		6.9 - 39	В	< 10	7
Volatile Carcinogens <sup>10</sup>		6.9 - 39			
No substances detected			В	< 1	< 1
Single VOC outside C <sub>6</sub> – C <sub>16</sub> :					
VVOC ( $< C_6$ ) <sup>11</sup>		5.3 - 6.9			
No substances detected			В	< 2	< 5
SVOC $(C_{16} - C_{22})^{12}$		39 - 52			
No substances detected			В	< 2	< 5

<sup>9)</sup> ID: A = quantified compound specific, B = quantified as toluene-equivalent

<sup>10</sup> Volatile carcinogens = VOCs according to EU Regulation No 1272/2008 Annex VI, cat 1A and 1B

<sup>11)</sup> VVOC = very volatile organic compounds, as defined in ISO 16000-6 (not accredited)

<sup>12)</sup> SVOC = semi-volatile organic compounds, as defined in ISO 16000-6 (not accredited)

TVOC is the sum of all individual substances with concentrations  $\ge 5 \ \mu g/m^3$  in the model room (in toluene equivalents). Level of identification of compounds is 100 % for all compounds  $\ge 5 \ \mu g/m^3$ .

#### Measurements uncertainty

The expanded measurement uncertainty of VOC result is 15 % (rel) and formaldehyde is 30 % (rel). For ammonia the measurement uncertainty is estimated to 20 % (rel).

See Appendix 1 for a gas chromatogram from the VOC determination and Appendix 2 for a photo of a test specimen. Appendix 3 is the Sampling report received from the customer.

#### **RISE Research Institutes of Sweden AB** Chemistry and Materials - Chemistry

Performed by

Examined by

Ulrika Johansson

Marcus Vestergren

#### Appendices

- 1. Gas Chromatogram
- 2. Photo of a test specimen
- 3. Sampling report

#### **RISE** Research Institutes of Sweden AB

REPORT



Appendix 1

### Gas chromatogram

Sample: **Allura Ease/Puzzle 63496EA7**, after 28 days (sampled volume 6.1L)

### Abundance



Time-->

TVOC between  $C_6$  and  $C_{16}$ , means compounds eluting between 6.9 and 39 minutes.

REPORT

Appendix 2

# Photo of a test specimen



Specimen for the chemical emission



Appendix 3

## **Sampling Report**

Sampler (Name, Company, contact info):	Manufacturer of the product (Company, address):			
Mikael Taberman	Forbo Flooring AB			
August Barks Gata 26				
421 32 Västra Frölunda				
Name of product:	Type of product:			
63496EA7	LVT Plattor			
Manufacturing Date:	Batch No:			
2020-03-23	59766			
Date of sampling:	Amount/size of material sampled:			
2020-04-03	2,28vm2			
	Packing material: Original + plastfolie			
Sample is taken from:	How was the product stored before sampling?			
Production line	På centrallager			
Stock / Storage x				
Miscellaneous				
-where, specify.				
If a sub-sample was collected from a larger mate taken: Ei aktuellt	rial amount, describe how the sub-sample was			
,				
Observations and remarks:				
Confirmation				
I hereby confirm that the sample was selected, taken and packed in accordance with the instructions.				
Date:	Signature: //			
2020-04-03	Mulli			