


FORBO C 930 ADHESIVE TECHNICAL DATA

RECOMMENDED FOR USE WITH:

- ColoRex® SD/EC Tile
- Marmoleum® Ohmex

SPECIFICATIONS:

- FloorScore Certified by SCS Global Services
- Acrylic Polymer
- Contains MicroSept™ anti-microbial protection
- Not flammable; 100% Solvent free
- Storage: Freeze-thaw stable: 1 cycle at 20° F (-6° C). If the pail is opened and found to be frozen, let it set closed and undisturbed at room temperature until thawed. **DO NOT** try to mix frozen adhesive.
- Shelf life: 2 years in unopened container
- Appearance and Odor: White with gray conductive fibers, with little or no odor
- VOC Emissions: 0 grams per liter (calculated per CA South Coast Rule 1168)
- Spread Rate: Approximately 125 square feet per gallon
- Available in four gallon units only



INSTALLATION RECOMMENDATIONS:

Recommended Substrates: All grade levels of concrete, approved suspended wood floors and approved existing resilient floors. The substrate must be dry, clean, smooth, and structurally sound. For concrete substrates, the moisture vapor emission rate must not exceed 8.0 lbs. per 1,000 square feet in 24 hours as determined by testing conducted in strict accordance with the latest version of ASTM F 1869. The internal relative humidity must not exceed 85% as determined by testing conducted in strict accordance with the latest version of ASTM F 2170. The surface pH of concrete slabs must not exceed a pH of 10. Concrete substrates with pH readings less than 7.0 or above 10.0 will require remediation prior to installation.

1. Areas to receive material should be clean, fully enclosed and weather tight. The permanent HVAC should be fully operational and controlled and set at a minimum temperature 65° F (18.3° C). If this is not possible, the areas should be acclimated and controlled by means of temporary HVAC to the service level conditions expected during occupancy. The temperature and humidity should range from 75° F ± 10° F (23.9° C ± 5.5° C) with a 50% ± 10% ambient relative humidity. These conditions **MUST** be established at least seven days prior to beginning the installation, maintained during the installation, and continued for at least seven days following the installation.
2. The substrate must be free of all foreign materials including, but not limited to, dust, solvent, paint, wax, oil, grease, residual adhesive, adhesive removers, film-forming curing compounds, silicate penetrating curing compounds, sealing, hardening, or parting compounds, alkaline salts, excessive carbonation or laitance, mold, mildew, and other foreign materials that might affect the rate of moisture dissipation from the concrete, the adhesion of resilient flooring to the concrete or cause a discoloration of the flooring from below.
3. Always conduct adhesive mat bond tests before beginning the installation. Bond testing will aid in identifying both the working characteristics of the adhesive, such as the appropriate open and working times for the site conditions, and also any potential bonding problems to the substrate.
4. Trowel recommendation: 1/16" x 1/16" x 1/16" square notch trowel. Because of the conductive fibers in the adhesive, ***be sure to clean the trowel notches frequently in order to maintain the proper spread rate.*** Replace the trowel when proper coverage is no longer attainable.
5. The open time and working time of adhesives will vary depending on site conditions such as ambient temperature and humidity, the porosity of the substrate and air circulation. A general indication of proper open time is when a light touch produces transfer of adhesive to the finger, but a firm touch will flatten and "smear" the adhesive.
6. The adhesive should be allowed to develop body before placing the flooring material into the adhesive, but ***DO NOT ALLOW THE ADHESIVE TO DRY.*** The flooring material ***MUST*** always be placed into ***wet*** adhesive and rolled immediately. The flooring material ***must also remain in contact with the adhesive while the adhesive is drying and curing.*** Proper placement and rolling will result in a complete "explosion" of the trowel ridges, creating a continuous flat film of adhesive on the substrate and on the material backing.

FORBO C 930 ADHESIVE TECHNICAL DATA

7. Check for adhesive transfer frequently; there must be a **100% wet transfer** of adhesive to the material backing in order to achieve a secure bond.
8. Immediately roll the flooring in all directions using a 100 pound roller to ensure proper adhesive transfer. Additional rolling is required during adhesive setup to ensure that the material is flat and fully adhered.
9. Remove fresh adhesive residue immediately with a clean white cloth. Dried adhesive can be removed with a clean white cloth and a properly diluted solution of neutral pH cleaner or with Forbo Adhesive Remover. The area must then be rinsed with clean, cool water to remove all residue from the floor. Refer to the Forbo Commercial Floor Care Guide for further information.
10. Keep the lid on the pail when not in use.
11. Do not allow heavy traffic or rolling loads for a minimum of 72 hours following the installation. Additional time may be necessary if the installation is over a non-porous substrate.
12. In order to allow the adhesive to dry and cure properly, wait a minimum of five days following the installation before conducting wet cleaning procedures or initial maintenance. Additional time may be necessary if the installation is over a non-porous substrate.

For additional information, Forbo's Installation and Floor Care Guidelines are available for download at www.forboflooringNA.com, or contact Forbo Product Support & Education Services at +800 842 7839.