

Installing Over Underfoot Heating

General Advice

Forbo PVC, Linoleum, Tessera and Flotex floorings are suitable for use in conjunction with under floor heating systems. The requirements for the installation of all resilient flooring products to subfloors incorporating under floor heating are detailed in AS1884:2021.

The following statement agreed by all members of the Resilient by Flooring Manufacturers Association and the Contract Flooring Association further clarifies these requirements and forms part of our installation recommendations.

“It is imperative that the under floor heating systems have been previously commissioned and found to be functioning correctly prior to the floor finish being installed. Ensure that the under floor heating system is switched off 48 hours prior to the floor covering installation commencing and remains off for at least 48 hours after the installation is complete.

During the period of decommissioning of the under floor heating system, an alternative heating source should be provided, if required, to ensure that the area of installation is kept at a constant temperature of 18°C– 27°C. Gradually increase the temperature over a number of days by only a few degrees per day until the desired room temperature is reached.

The temperature should never exceed the industry agreed maximum of 27°C at the underside of the floor covering (the adhesive line). Failure to follow these guidelines can result in the floor covering de-bonding, joints opening, and on some occasions discolouring, all of which can occur within a long or short period of time.”

If in any doubt contact us:

Forbo Flooring Systems Pty Ltd

Tel: 1800 224 471

Fax: 1800 662 566

Info.au@forbo.com

www.forbo-flooring.com.au

Additional reference documents and information:

www.forbo-flooring.com.au/installation

AS 1884:2021